



Inside the Vehicle's Cab




Note: Blue light on switch lits up when high beam is on



Inside the Vehicle's Cab

Under the Vehicle's Hood




Under the Vehicle's Hood

On the Plow Headlights

53807-M Auxiliary light kit BOM

#	Part#	Description	QTY
1	53810-B	Auxiliary Light Harness	1
2	53811-N	Rocker Switch (Blue Light)	1
3	800041	Relay	2
4	800070	Sealed female dummy plug	2
5	53809-M	ALK Switch bracket, plated	1
6	53625-05-N	Low profile fuse holder	1
7	53625-07-N	Micro fuse holder	1
8	53625-08-N	Micro 10A fuse	1
9	53625-09-N	Low profile 10A fuse	1
10	HH-00455-007	#8 x 3/4" pan head	5
11	761245	Butt Connectors	2



DS - Driver Side  
CS - Curb Side