


## Mounting Kit 53352-MKPB-QLIV

F150 4x4 2009-2010, 2013-14

For the snowplow lights this kit requires: 800084 or 800086 Light kit, 53617-M wiring kit and 800034 Adapter (vehicle's bulb H13)







Item	Part #	Description	Quantity
1	53853-HANDLE	QLIV SD2 Lift frame c/w handle	1
2	53551-C	Spreader Bar QLIV	1
3	53353-D	Mounting Bracket	1
4	53360-A	Inside plate	1
5	HH-00971-105	7/16"-14x 1 ½" Carriage Bolt G5	2
6	HH-00340-002	7/16"-14 Nylon Insert Locknut	2
7	50069-C-GA	Lift Channel (1 ½" cylinder)	1
8	НН-00972-153	<sup>3</sup> / <sub>4</sub> " x 31/2" HHCS	2
9	НН-00973-007	<sup>3</sup> / <sub>4</sub> " Thin Collar Lock nut	3
10	HH-00972-149	3/4" x 2½" UNF Cap screw	1
11	52373-M	Jack Assembly	1
12	52757-M	Rivet Ass'y	1
13	52320-A	½" bolt with 14" welded handle	8
14	53858-04-M	Arctic Logo Plate c/w backing plate	1
15	HH-00460-002	1/2-20 Hex nut	18
16	HH-00457-001	1/2 Lock washer	18
17	HH-00972-130	5/8-18 x 2 UNF Cap screw	8
18	HH-00457-003	5/8 Lock washer	8
19	HH-00460-001	5/8-18 Hex nut	8
20*	53352-M-WB	53352 Bolt bag c/w welded bolts	-

Items marked with \* are not shown on drawing



## **GENERAL INFORMATION**

## **Customer must be aware of following:**

Arctic Equipment Manufacturing Corporation (Arctic) does not assume liability for damage to your motor vehicle resulting from the attachment or use of an Arctic snowplow. The purchaser assumes all vehicle risk associated with the attachment and operation of this snowplow.

The Arctic snowplow you purchase must be used only on vehicles equipped with the manufacturer's snow plow preparation package. Snow plowing without the original plow preparation package may damage your vehicle. The added weight may impair the operation and control of your vehicle. Snow plowing with a vehicle not recommended for that purpose by the manufacturer may void your new vehicle warranty. If your vehicle is not equipped with an original snow plow preparation package, additional equipment may be necessary before snow plowing. Please consult your vehicle and snowplow dealers prior to the purchase and installation of the snowplow. The installation of such parts however is not a full substitute for the original equipment snowplow preparation package.

Before drilling any holes in the firewall or frame, move brake lines, fuel lines and/or electrical wiring from the path of the drill. Brake and fuel lines must also be clear of any fasteners.

All bolts should be installed from the inside of the truck frame so that the lock washers and nuts are accessible for re-tightening.

If a slotted hole in the truck frame is utilized, then a flat washer must be used under the bolt head. Please use LOCTITE®, or similar locking product on ALL mounting hardware(blots, nuts, etc.).

Do not tighten any bolt assemblies until all fasteners and components are installed, unless otherwise specified.

After first use, re-tighten all mounting bolts, thereafter, check mounting bolt tightness periodically.

Before proceeding, read instructions carefully and familiarize yourself with the components and hardware.



## INSTALLATION INSTRUCTIONS

- 1. You may Remove the bottom splash pan and tow hooks. Note: After installation of mounting kit and spreader bar, return a splash pan, tow hooks and hardware to customer.
- 2. Install inside frame plate (4) and slide mounting bracket (3) against frame as show on the drawing (use only back tow hook hole and exiting hole in the frame). Secure mounting bracket (3) to vehicle frame using ½" lock washers (15) and ½" hex nuts (16). Be sure that mounting bracket front and back is tight against vehicle frame before drilling side holes (4 per vehicle frame side).

Using existing holes in the mounting bracket (3) (two in the front and two at the back) drill 17/32" hole in the vehicle frame. After drilling install ½" welded bolts (13) and secure using ½" lock washers (16) and ½" hex nuts (15). Do not tighten any hardware until instructed to do so.

(Install welded bolts on the back through existing in the vehicle frame as shown on this picture.)



- 3. Insert the spreader bar (2) between mounting bracket side plates. Insert 5/8" x 2 " bolts (17) from inside spreader bar (2)
  - through mounting bracket holes and secure using 5/8" lockwasher (18) and 5/8" nuts (19).

Note: Please use LOCTITE®, or similar locking product on ALL mounting hardware(blots, nuts, etc.).

- 4. Torque all fasteners according to torque chart.
- 5. Slide lift frame (1) inside of spreader bar (2).



- 6. Torque all fasteners according to the torque chart.
- 7. Return any unused items to the customer so that the vehicle can be returned to its original condition if the snowplow is removed.
- 8. See separate installation instructions for the hydraulic power unit, wiring and controls.



Torque Chart (Ft. Lb)				
Size	Grade 5 Bolt	Grade 8 Bolt		
1/4 - 28	8	11		
5/16 - 24	15	22		
3/8 - 24	28	40		
7/16- 20	44	63		
1/2- 20	69	97		
5/8-18	138	195		
3/4-16	241	341		
Note: Torque values are for plated bolts only.				